

STANDARD DEPARTURE CHART-INSTRUMENT

RJOW / IWAMI

SID and TRANSITION

SAMBA TWO DEPARTURE

RWY11 : Climb RWY HDG to 800FT, turn left HDG351°, ...
RWY29 : Climb RWY HDG to 700FT, turn right HDG081°, ...
...to intercept and proceed via IME R036 to SAMBA.
Cross SAMBA at or above 7000FT.

Note RWY11 : 5.7% climb gradient required up to 1700FT.
OBST ALT 1177FT located at 4.83NM 093° FM end of RWY11.

IZUMO TRANSITION

From over SAMBA, via XZE R252 to XZE VOR/DME.
Cross CARNY at or below 13000FT, cross BAARU at or below FL230.

